

C-Bus Wireless is a 240V Wireless Control System that uses the same wires as a normal light switch.

You can now simply pull out the old light switch and put in a new C-Bus Wireless one using the same active and switched active. You don't even need a neutral! In fact, you can even use it as a stand-alone unit, which is great for customers who like the look of Neo or glass Ulti Saturn switches. But it doesn't stop there. You can set up 2-way switching between any switch! Add some plug adaptors and you can dim lamps or control appliances too.

It's that easy.



Great looking switches

Colours and styles to suit any decor.



Labelled for convenience

Label buttons so you know what each one does.




Plug Adaptors

Control lamps, appliances and more!



Remote


Total control from the comfort of your chair.




Switches that talk to each other.

C-Bus Wireless wall switches talk to each other like your garage door opener or car's keyless entry. They have built in dimmers or timers, can do two-way, three-way switching (or more), can turn on appliances, dim lamps and can even be operated by remote control. And remember, they use the same 240V wires as a normal light switch. You don't even need a computer to set them up.








C-Bus Wireless wall switch



NO NEUTRAL REQUIRED!



Get your switches talking



Step 1

Press & hold top two buttons on first switch for 10 sec until they flash alternately.



Step 2

ΘΘ ΘΘ

Press & hold top two buttons on next switch for 10 sec

until they flash alternately.

do these within 5 sec





Step 3

Press top two buttons again while they are still flashing rapidly.



Step 4

Press & hold top left button and do two quick presses to top right button.



Step 5

Press & hold top two buttons on either switch for 1 sec.



You're done!

2 way switching







Press & hold the two buttons that are connected to the light you want to operate for 10 sec until they flash alternately.





Step 2

Press the button that controls the light you want to operate. That light should now turn on.



Step 3

Press the button on other switch that you want to control the light you have turned on.



Step 4

Press & hold top two buttons on either switch for 1 sec.



You're done!

Scenes

Part 1 - Create your Scene button



Step 1

Press & hold top two buttons for 10 sec until they flash alternately.



Step 2

Double quick-press the button you want to control your scene.



Step 3

Press & hold top two buttons for 1 sec.



You're done!

Part 2 - Creating your scene







Step 1

Press & hold the scene button for 10 sec until it flashes.







Step 2

Turn on any lights to the desired level for your scene. This may include plug adaptors with lamps.





Step 3

Press the scene button for 2 sec



You're done!

Remote control



Step 1

Press & hold top two buttons on any switch for 10 sec until they flash alternately.



Step 2

Remove the remote back cover and slide switch to the "learn" position.



Step 3

Press the button on the remote you want to control your light.



Step 4

Press the button on the switch that you want to control with your remote.



Step 5

Press & hold top two buttons for 1 sec.




Step 6

Slide switch to "use" mode and replace back cover.



You're done!



C-Bus Wireless is the perfect solution for:

- home theatre room a great place to introduce remote control of lights and lamps
- call-outs to replace existing switches – C-Bus Wireless offers built in two-way switching, dimmer and timer benefits
- existing homes or home renovations
 update with the look of Neo and
 Ulti Saturn
- customers who feel more comfortable with traditional cabling
 start with a single room
- those who want automation, but can't afford to do the whole home – add to the installation at any time
- existing C-Bus installations requiring remote control of appliances – a great new addition.

C-Bus Wireless is the perfect introduction to home automation.









Provide a multitude of options for your customers using a combination of C-Bus Wireless products.

ENTERTAINMENT









Cinema Mode

Recreate that cinema experience in your very own lounge room. Get comfortable as you sit down to watch a movie or play a DVD and adjust the lights to the exact level you want, all via remote control.









Party Mode

Friends over for dinner? Hit party mode and welcome guests with outdoor and entrance lighting, water features activated, and soft lighting at the dinner table.

COMFORT





Goodnight Mode

Get into bed and press the "All Off" button on your remote control and all your house lights and lamps will gently fade off.

Once you've had this you'll wonder how you lived without it!







Night time

Need to check on the kids or visit the bathroom during the night? Create a dimly lit scene to light your way without disturbing family members.

CONVENIENCE







2-way and 3-way switching

Forget trenching walls and chasing extra cables.
C-Bus Wireless switches can talk to each other from one side of the house to the other.









Welcome home

Turn on the kitchen, hallway and pathway lights with the press of one button.









Spa baths, pool pumps and garden lights

Turn on or off appliances inside and out via remote control from anywhere in the house.











Helping the elderly and disabled

Repetitive switching can be a difficult task for the elderly or disabled. C-Bus Wireless can be set-up to simplify these tasks from a single button or remote control.





Panic Mode

Hear a strange noise? Hit "Panic Mode" and light up your whole house instantly. All external as well as internal lights will turn on to maximum brightness.



Product of

Clipsal Integrated Systems Pty Ltd

Member of Clipsal Australia Holdings Group ABN 15 089 444 931

Head Office

12 Park Terrace, Bowden South Australia 5007

PO Box 103 Hindmarsh South Australia 5007

Telephone (08) 8440 0500 International +61 8 8440 0500

Facsimile (08) 8346 0845 International +61 8 8346 0845

Internet www.clipsal.com/cis E-Mail cis@clipsal.com.au

CIS Technical Support Hotline 1300 722 247

National Customer Service Enquiries:

1300 2025 25

National Customer Service Facsimile: 1300 2025 56

International Enquiries

International Sales and Marketing

Telephone +61 8 8269 0587 Facsimile +61 8 8340 7350 E-Mail export@clipsal.com.au

New Zealand

Clipsal Industries (NZ) Ltd
Telephone +64 9 576 3403
Facsimile +64 9 576 1015
E-Mail headoffice@clipsal.co.nz

Customer Service

Free Facsimile (0508) 250 305 Auckland/Mobile Phone (09) 572 0014 Free Phone (0508) CLIPSAL 2547725

Malaysia

Clipsal Integrated Systems (M) Sdn Bhd Unit 3-2, Level 3, C P Tower No.11, Jalan 16/11, Seksyen 16, 46350 Petaling Jaya, Selangor, Malaysia Telephone +60 3 7665 3555 Facsimile +60 3 7665 3155 E-Mail sales@cisasia.com.my

Singapore

Clipsal Singapore Pte Ltd 5, Fourth Chin Bee Road 619 699 Singapore

Telephone +65 6415 3211
Telephone +65 6415 3232
Facsimile +65 6415 3289
E-Mail +65 6415 3289
sales@cisasia.com.sg

International Representatives

China

Clipsal China Limited Telephone +86 755 8237 5959

Greece

Schneider Electric AE
Telephone +30 69 4646 3200

Hong Kong

Clipsal Integrated Systems (HK) Limited Telephone +852 2487 0261

India

Schneider Electric India Pvt Ltd Telephone +91 11 5159 0000

Indonesia

PT Clipsal Graha Nusa Telephone +62 21 630 6430

Korea

Clipsal Korea Co. Ltd Telephone +822 549 5550

Pakistan

Clipsal Pakistan (Pvt) Ltd Telephone +92 21 506 7278

Philippines

Clipsal Philippines Inc.
Telephone +632 683 0275-78

South Africa

Clipsal South Africa (Pty) Ltd Telephone +27 11 314 5200

Taiwan

Clipsal (Taiwan) Co Ltd Telephone +886 2 2558 3456

Thailand

Clipsal Thailand Ltd Telephone +66 2 952 5338 Telephone +66 2 952 5342

United Arab Emirates

Clipsal Middle East Telephone +971 6 5570 777

United Kingdom

Clipsal Integrated Systems C/o Schneider Electric Telephone +44 870 608 8 608

Vietnam

Clipsal - VTEC

Telephone +848 856 3002

C-Bus[®] is a registered trademark of Clipsal Australia Pty Ltd.
C-Bus2[™] is a trademark of Clipsal Australia Pty Ltd.

III CLIPSAL°



You can find this brochure and many others online in PDF format at: clipsal.com

Follow the links off the home page or access the following page directly: clipsal.com/wat_lib_pdf.cfm

clipsal.com/cis

Clipsal Integrated Systems Pty Ltd reserves the right to change specifications, modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© Clipsal Integrated Systems Pty Ltd 2005. All rights reserved.

This material is copyright under Australian and international laws. Except as permitted under the relevant law, no part of this work may be reproduced by any process without prior written permission of and acknowledgement to Clipsal Integrated Systems Pty Ltd.